

Public Abstract

First Name:Maslina

Middle Name:Tarin

Last Name:Othman

Adviser's First Name:Shubhra

Adviser's Last Name:Gangopadhyay

Co-Adviser's First Name:

Co-Adviser's Last Name:

Graduation Term:WS 2007

Department:Electrical Engineering

Degree:PhD

Title:Spectroscopic Ellipsometry Analysis of Nanoporous Low Dielectric Constant Films Processed via Supercritical Carbon Dioxide for Next-generation Microelectronic Devices

This research will address issues at the back-end-of-line in microelectronics fabrication, specifically the need for Low-k extendibility. The International Roadmap for Semiconductors (2005) suggested that interconnect insulation must be replaced with a material having an ultra-low dielectric constant (k) of less than 2.0 and can withstand rigorous current process integration. Creating porosity in the films produces k -values as low (1.0) as air.

Supercritical Carbon Dioxide (SCCO₂) process is utilized to create pores, remove water, repair plasma-damaged sample and seal pores. These multi-step processing does not only produce low-k film but also create device reliability. Spectroscopy ellipsometric (SE) analysis is used to evaluate the performance of each process on porous film. In SE analysis, Cauchy, Bruggeman Effective Medium Approximation and graded models are used to model the processed samples. The depth profile SE analysis demonstrates the individual process performance based on its changes of refractive index (n) throughout the film thickness. SE also provide important film properties like thickness, porosity etc. In addition to SE, Fourier Transform Infra-red (FT-IR), Scanning Electron Microscopy (SEM) and electrical characterizations are used.

Results show that SCCO₂/co-solvents can extract porogens and remove water effectively at a significantly shorter time (less than or equal to 1hr) and at a low temperature (less than or equal to 160 degrees C) without thickness shrinkage in contrast with thermal annealing (450 degrees C and 5hrs) without significantly shrinkage. SCCO₂/TMCS removes water and terminates silanol group with methyl group; preventing water re-adsorption which increases k . The dense layer on the sample surface that formed through the vapor treatment/HMDS helps to seal pores and prevent metal diffusion.